


How to Order 48 Series (MACConnect™)

48A - X X X - X X X - LXXX - X XX (Latching)
48A - X X X - X X X - GXXX - X XX (Standard)

Solenoid Assembly




How to Order

Adapter Kits

MAConnect™ Adapter Assembly

(Positive Commons)

M-48001 - XX - X X




Use MOD 1705 for Negative Commons

MAConnect™ Adapter Assembly

(Required For Connecting To A Remote Stack)

M-48002 - XX - X X



48 SERIES MACONNECT SHOWN WITH MULTI-PIN

